




Connect your OutCast Speaker to Sonos and add an outdoor "Portable" Zone

Did you know your OutCast speaker connects to Sonos? Here's how:


Soundcast portable speakers make a great addition to any Sonos music system. Simply add a Sonos Connect (ZP90) to your Soundcast OutCast or OutCast Jr. and the Soundcast UAT transmitter. Now you can easily add a weather-resistant battery powered "Portable" zone to your Sonos.

What You'll Need to Connect:



Step 1:


Using the RCA audio cable included in the UAT package, connect "audio out" located on the rear panel of your Sonos connect to "audio in" on the Soundcast UAT transmitter.






Step 2a:

Ensure that your UAT is connected to an AC outlet and that your OutCast speaker and UAT are set to the same channel.



Step 3

Open your Sonos app, look under Sonos "Connect Zone Menu" add to group under "Portable" and your OutCast speaker will be ready to play music outdoors.



Note:

- *Setting the Sonos Connect (ZP90) zone's audio to 'variable' will maintain volume control from the Sonos app and will also require volume control on the Soundcast speaker(s).*
- *Setting the Sonos Connect (ZP90) zone's audio to 'fixed' will deliver full volume from the Sonos and all volume will be controlled by the Soundcast speaker(s).*
- *You may also operate up to two Soundcast speakers per transmitter.*
- *Refer to the user's manual of your Sonos system or your Soundcast system for addition setup instructions not mentioned in this guide.*